



1. Replace the DU

2. Replace the SUs

3. Keep the CP / IM

4. Upgrade the software

5. Enjoy your Pro system



Refer to the installation guides and operator's manuals at zipwake.com for more information about installation and software upgrade