

The right way to inflate your DAN-FENDER product



CORRECT INFLATION

Due to the high quality of the metal valve, we recommend to use an air-compressor for inflation of DAN-FENDER products.

See www.danfender.com for correct measurements for each product!



ONBORD THE BOAT

If you need to inflate extra air during the season, then always/only use the small and special made DAN-FENDER handpump.



IMPORTANT!

Do not overinflate fenders & buoys, it will only weaken the product. After inflation fenders & buoys shall not become as hard as a rock, you should be able to easily press a small "dent" in the product with your finger.

Save Money & Time

How to replace the valve in DAN-FENDER products

If a valve is leaking or by "accident" pressed inside the fender/buoy, then a new valve can easily be installed...and the fender/buoy is as good as new again...!



Remove the faulty valve:
Screw a 3mm screw inside the centre of the valve and pull it out with a tong (tool).



Install a new valve:
Push (with the help of a screwdriver) the new valve into the same position as the old, and inflate the fender/buoy again.

Instead of sending fenders/buoys forwards and backwards (or issuing credit notes), simply send your customer a new valve together with this guidance.

It is much cheaper and it saves both you and your customer a lot of time and MONEY. It is easy and great service...

