


Standard Tactile Trim Tab Switch w/ Retractor Wiring Diagram - Part # 15069-001 (124SSR)

Note: In all cases,
make sure the control box
is mounted with the wires
facing down toward the deck.



The keypad cable needs
slack and should not be
bundled with other cables.
Failures to do so may result
in the plug breaking while in
use.

In order to activate the retractor feature, the orange accessory wire needs to be connected to an analog engine tach signal or a 12V non-engine switch. The system is operational without the retractor feature if the orange wire is not connected.

This product must be wired exactly as shown above. Removal of any of the included Deutsch connectors or failure to wire the trim tab retractor as shown will cause the cancellation of all warranties by the manufacturer.