

ACS R/RP

Eltrim connection

Connecting the ACS R/RP to Eltrim trim tabs

Below, find an example of the ACS R/RP control unit connected to Eltrim trim tabs. The terminals 3,4,5,6 are connected to the actuator motors. The original control panels and steering unit have to be removed.

After installation, verify the control direction according to instructions in the user's manual. Should a trim tab move in the wrong direction, it is easily corrected by reversing the polarity.

